



Pro-Lock Valve Lockout System

OPERATING INSTRUCTIONS



1. Use the Pro-lock with the PVC coated steel wire provided, cut to the required length.

Note: To avoid possibility of minor cuts from the potential frayed cable ends:

- a) When cutting PVC cable, be sure not to leave any protruding steel cable beyond PVC coating (Use sharp cutters).
- b) As added protection against this, it is recommended, that when securing pro-locks that protective gloves are worn.

2. Secure the object to be locked with the wire.

3. Unscrew the top of the Pro-lock far enough to enable introduction of the wire from the sides.



4. Slot the wire into the lock **(No threading of wire is necessary)**

5. Screw down the top, hand tight.

6. Slide the Pro-lock to the optimum position **(much like the knot of a neck tie)**

7. Hard tighten using the Operating Tool provided..

8. For added security fit padlocks or security seal, as necessary.



[Top of Page](#)

[Site Map](#) - [Search](#) - [Terms](#) © 2010 Pro-Lock Valve Lockout Ltd.

PRO-LOCK VALVE LOCKOUT LTD.
UNIT 4, THE OLD COAL YARD • HALL GATE LN • PREESALL • LANCS • FY6 0PJ • U.K.
Tel: +44 (0)1253-811333 • Fax: +44 (0)1253-813030 • E-mail: info@pro-lock.co.uk

[Home](#)

Valve Lockout
Ball Valve LO
Gate Valve LO
Butterfly Valve LO
Needle Valve LO

Benefits
Benefits of Pro-lock
Operating Instructions
Specification
Testing

Special Pro-locks
Large and Hex head
Stainless Steel
Security

Padlocks & Hasps
Brass
Xenoy
Stainless Steel

Polypropylene Seals
Standard
Large Flag
Isolation Tag Seals